


- A. Take the headboard (1) and slot into the back side panels (5). Do the same with the footboard (2) slot into the front side panels (4).
- B. Pull the front / back side panels (4 + 5) together, then insert the centre support (3) to the holes in the side on oneside, then repeat for the other side.
- C. For front storage box assembly, hook front panel (8a) into side panels (8c), then slide in base panel (8b).
- D. Put slats (6) in place on the side panels (4 + 5), take the screws (7) and put into the slats (6) with screw driver (not supplied). Lift whole front storage box and hook onto footboard of the bed.



IMPORTANT

USER GUIDE

Thank you for choosing a KIDSAW product. Please take a little time to read the important safety notes detailed below. This will ensure many years of happy, safe use.

SAFETY WARNINGS

WARNINGDO NOT PLACE THIS CHILD'S BED NEAR HEAT SOURCES, WINDOWS AND OTHER FURNITURE.WARNINGDO NOT USE THIS CHILD'S BED IF ANY PART IS BROKEN, TORN OR MISSING.

ADDITIONAL INFORMATION

- The JCB junior bed conforms to **BS 8509:2008+A1:2011**.
- The bed is intended for use by a child from the age of **18 months to 4 years old**.
- We recommend a cot mattress of dimensions H.10 x W.70 x D.140cm to be used with this bed.
- Periodically check the bed to make sure all fittings are tightened securely.
- Make sure the bed is not placed too close to other furniture, windows, blind cords, curtain pulls or other strings and cords due to children bouncing, jumping and climbing the bed. We recommend you place the bed tight to a wall or have at least 300mm between it and the bed.
- **ONLY** use spares approved by Kidsaw Ltd.
- **ONLY** adults should assemble this bed.

CARE & MAINTENANCE


- All surfaces should be wiped over using a damp cloth to clean.
- Never clean with abrasive, ammonia based, bleach or spirit type cleaner

KEEP FOR FUTURE REFERENCE & READ CAREFULLY

JCB JUNIOR BED



www.facebook.com/kidsaw



INSTRUCTIONS



MAKES FURNITURE CHILDS' PLAY

Kidsaw Ltd Tel: +44 (0)1455 848969 Email: support@kidsaw.co.uk www.kidsaw.co.uk

4

3